

## V1S 固件说明

- 一、请使用神牛固件升级软件 G3 打开该固件进行升级。G3 可在官网上下载。
- 二、版本号查看方法：开机后按 “MENU” 按键，进入 C.Fn 菜单。右上角显示 Ver x.x 为版本号。
- 三、版本说明：

版本	更新内容	日期
V1.6	1、替换字符，“RX” 替换 “Slave”。	2020-07-16
V1.5	1、增加 mode 按键锁住功能（长按 MODE 按键 2 秒）。	2020-06-20
V1.4	1、改善热保护系统。 2、调整 LED 控制方式。 3、增加打开相机 WL 模式时有警示。	2019-08-17
V1.3	1、优化 V1S 和 Sony 相机之间的通讯。	2019-06-05

注：详细规格请在官网（[www.godox.com](http://www.godox.com)）下载最新说明书。

## V1S Firmware Instructions

- 1. Please update the firmware with Godox firmware update software G3. G3 can be downloaded on the official website.**
- 2. Firmware Version Checking:** Press the “MENU” button and enter C.Fn menu after turning on the camera flash. The firmware update version (e.g. Version xx will read U-xx) will be displayed on the LCD panel.
- 3. Version Instructions:**

Version	Updated Contents	Date
V1.6	1. To replace the display sign “Slave” with “RX”.	2020-07-16
V1.5	1. To add the lock function by pressing the MODE button for 2 seconds.	2020-06-20
V1.4	1. To improve the heat protection system. 2. To adjust the control methods of LED. 3. To add warning when turning on the camera’s WL mode.	2019-08-17
V1.3	1. To optimize the communication between V1S and Sony cameras.	2019-06-05

**Note: For more details, please download the newest instruction manual on the official website [www.godox.com](http://www.godox.com).**